

Instructions for Installation of Shielding with Instant Transfer Adhesive

Shielding should be applied to only clean and smooth mounting surfaces at room temperature (65° F or higher).

Follow these 3 steps:

1. Smooth the mounting surface with an emery cloth if necessary and clean with a suitable commercial solvent to remove any oil or film. Avoid finger prints on the mounting surface after cleaning.
2. Peel off the protective paper backing and avoid finger contact with the adhesive.
3. Be sure the strip is in the correct position and then press down firmly to insure a good bond over the contact surface. Avoid any repositioning after the shielding is in place, for this will reduce the effectiveness of the adhesive and distort the shielding.

Allow 24 Hours for Complete Curing Time.

Tech-Etch

www.tech-etich.com/shield

**ISO 9001:2008
REGISTERED**

TECH-ETCH, INC., 45 Aldrin Road, Plymouth, MA 02360 • TEL 508-747-0300 • FAX 508-746-9639